


FIG. 1


A 自車側ナビゲーション装置



A OWN VEHICLE NAVIGATION APPARATUS

- 11 INPUT SECTION
- 12 CURRENT POSITION ACQUISITION SECTION
- 13 STORAGE SECTION
- 14 TRANSMISSION SECTION
- 15 RECEPTION SECTION
- 16 CONTROL SECTION
- 17 DISPLAY SECTION

B 他車側ナビゲーション装置



B OTHER VEHICLE NAVIGATION APPARATUS

- 11 INPUT SECTION
- 12 CURRENT POSITION ACQUISITION SECTION
- 13 STORAGE SECTION
- 14 TRANSMISSION SECTION
- 15 RECEPTION SECTION
- 16 CONTROL SECTION
- 17 DISPLAY SECTION

FIG. 2






FIG. 3

[図3] A 自車側ナビゲーション装置



B 他車側ナビゲーション装置



A OWN VEHICLE NAVIGATION APPARATUS

- | | |
|---------------------------------|---|
| 21 INPUT SECTION | 22 CURRENT POSITION ACQUISITION SECTION |
| 23 MAP DATA ACQUISITION SECTION | 24 ROUTE SEARCH SECTION |
| 25 STORAGE SECTION | 26 TRANSMISSION SECTION |
| 27 RECEPTION SECTION | 28 CONTROL SECTION |
| 29 DISPLAY SECTION | |
- B OTHER VEHICLE NAVIGATION APPARATUS
- | | |
|---------------------------------|---|
| 21 INPUT SECTION | 22 CURRENT POSITION ACQUISITION SECTION |
| 23 MAP DATA ACQUISITION SECTION | 24 ROUTE SEARCH SECTION |
| 25 STORAGE SECTION | 26 TRANSMISSION SECTION |
| 27 RECEPTION SECTION | 28 CONTROL SECTION |
| 29 DISPLAY SECTION | |

[図4]




FIG. 4

Kimihiko NOMURA, et al.
NAVIGATION APPARATUS
NGB-106US Customer #52473

- (a)
- OWN APPARATUS A
- S31 INPUT VEHICLE FEATURE INFORMATION AND DESTINATION
 S32 ACQUIRE CURRENT POSITION INFORMATION AND DISPLAY MAP
 S33 DISPLAY SEARCH ROUTE ON MAP SCREEN
- S34 STORE SEARCH ROUTE INFORMATION AND CURRENT POSITION INFORMATION
- S35 TRANSMIT INFORMATION TRANSMISSION REQUEST TO OTHER APPARATUS B
- S36 RECEIVE VEHICLE FEATURE INFORMATION, CURRENT POSITION INFORMATION, AND SEARCH ROUTE INFORMATION FROM OTHER APPARATUS B
- S37 DOES OTHER VEHICLE RUNNING ON THE SAME ROUTE AS OWN VEHICLE?
- S38 CALCULATE DISTANCE FROM OWN VEHICLE TO OTHER VEHICLE
- S39 DISPLAY CALCULATED DISTANCE AND VEHICLE FEATURE INFORMATION OF OTHER VEHICLE
- (b)
- OTHER APPARATUS B
- S41 INPUT VEHICLE FEATURE INFORMATION AND DESTINATION
 S42 ACQUIRE CURRENT POSITION INFORMATION AND DISPLAY MAP
 S43 DISPLAY SEARCH ROUTE ON MAP SCREEN
- S44 STORE SEARCH ROUTE INFORMATION AND CURRENT POSITION INFORMATION
- S45 RECEIVE INFORMATION TRANSMISSION REQUEST FROM OWN APPARATUS A
- S46 TRANSMIT VEHICLE FEATURE INFORMATION, CURRENT POSITION INFORMATION, AND SEARCH ROUTE INFORMATION TO OWN APPARATUS A

[図5]

